

## Compatibility

### [Precautions on use]

- The compatibility of devices not listed on this website has not been checked. In addition, depending on the device, specifications may change after the compatibility check and the information may differ from the information in the list.
- The results of the compatibility check may differ depending on the use conditions, settings, and functions of the mobile device.
- When updating the OS of the mobile device (such as Android, iOS), the stored information (pairing) may become invalid. If it becomes invalid, delete the paired device from both the mobile device and Mazda Connect and perform pairing again.

Manufacturer	Device	Software Version	Basic Features				Advanced Features				Messaging			Entertainment		Indicators		USB Functions					Applications	
		Device OS	Device Pairing	Handsfree Calling	Incoming Call	Call Hangup	Call Waiting	Phonebook Import - Name/Phone #	Phonebook Import - Contact Pictures	Call History	SMS/Text - Receive Message	SMS/Text - Send Message	SMS/Text - Notification	Bluetooth Audio - Music	Bluetooth Audio - Displays Song Info	Battery Level	Signal Strength	USB Connection	Plays Music	USB - Displays Song Info	Music Controls	Charge Device	Android Auto	Apple CarPlay
Alcatel	1S	Android 9	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	① ※8	✓	✓	✓	●	●	●	✓	✓	●	

- ※2 The number of incoming calls may not match the one shown on the device(mobile phone).
- ※3 Fast forward and fast reverse may not function during playback.
- ※5 The repeat folder, repeat one, and shuffle icons may not match the ones shown on the device(mobile phone).
- ※7 There may not be any sound output from the speaker during playback.
- ※8 After selecting song, song information may not appear.
- ✓ = Function is compatible with system operation
- ① = Function is compatible with system operation but may experience some limitations
- = This feature is not supported by this device at this time - please check back periodically for updates

Manufacturer	Device	Software Version	Basic Features				Advanced Features				Messaging			Entertainment		Indicators		USB Functions					Applications	
		Device OS	Device Pairing	Handsfree Calling	Incoming Call	Call Hangup	Call Waiting	Phonebook Import - Name/Phone #	Phonebook Import - Contact Pictures	Call History	SMS/Text - Receive Message	SMS/Text - Send Message	SMS/Text - Notification	Bluetooth Audio - Music	Bluetooth Audio - Displays Song Info	Battery Level	Signal Strength	USB Connection	Plays Music	USB - Displays Song Info	Music Controls	Charge Device	Android Auto	Apple CarPlay
Apple	iPhone 14	iOS 17.3	✓	✓	✓	✓	✓	① ②	① ※2	✓	●	✓	✓	① ※15	②	②	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 14 Pro	iOS 17.3.1	✓	✓	✓	✓	✓	① ②	① ※2	✓	●	✓	✓	① ※15	②	②	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 14 Pro Max	iOS 17.3	✓	✓	✓	✓	✓	① ②	① ※2	✓	●	✓	✓	① ※15	②	②	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone SE (2022)	iOS 17.3	✓	✓	✓	✓	✓	① ②	① ※2	✓	●	✓	✓	① ※15	②	②	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 13	iOS 17.3	✓	✓	✓	✓	✓	① ②	① ※2	✓	●	✓	✓	① ※15	②	②	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 13 Pro	iOS 17.3	✓	✓	✓	✓	✓	① ②	① ※2	✓	●	✓	✓	① ※15	②	②	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 13 ProMax	iOS 17.3	✓	✓	✓	✓	✓	① ②	① ※2	✓	●	✓	✓	① ※15	②	②	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 12	iOS 14.5	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 12 mini	iOS14.1	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone SE (2020)	iOS 14.6	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 11	iOS 15.1	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 11 Pro	iOS 15.1	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 11 Pro Max	iOS 14.3	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone XR	iOS 15.1	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone XS	iOS 15.1	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone XS Max	iOS 14.5	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone X	iOS 12.4	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 8	iOS 15.1	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 8 Plus	iOS 12.4	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 7	iOS 14.5.1	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 7 Plus	iOS 14.1	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	
Apple	iPhone 6s	iOS 14.5.1	✓	✓	✓	✓	✓	✓	① ※2	✓	●	✓	① ※4	①	✓	✓	✓	✓	✓	✓	✓	●	✓	

- ※2 The number of incoming calls may not match the one shown on the device(mobile phone).
- ※4 The repeat all icon may not be displayed.
- ※15 Album cover is not same as the device.(mobile phone)
- ✓ = Function is compatible with system operation
- ① = Function is compatible with system operation but may experience some limitations
- = This feature is not supported by this device at this time - please check back periodically for updates
- ② = This function has not been tested on this device

Manufacturer	Device	Software Version	Basic Features				Advanced Features				Messaging			Entertainment		Indicators		USB Functions					Applications	
		Device OS	Device Pairing	Handsfree Calling	Incoming Call	Call Hangup	Call Waiting	Phonebook Import - Name/Phone #	Phonebook Import - Contact Pictures	Call History	SMS/Text - Receive Message	SMS/Text - Send Message	SMS/Text - Notification	Bluetooth Audio - Music	Bluetooth Audio - Displays Song Info	Battery Level	Signal Strength	USB Connection	Plays Music	USB - Displays Song Info	Music Controls	Charge Device	Android Auto	Apple CarPlay
Google	Pixel 4	Android 11	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	① ※8	✓	✓	✓	●	●	●	✓	✓	●	
Google	Pixel 4a	Android 11	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3	①	✓	✓	✓	●	●	●	✓	✓	●	
Google	Pixel 3a	Android 10	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3	①	✓	✓	✓	●	●	●	✓	✓	●	
Google	Pixel 3a XL	Android 10	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3	①	✓	✓	✓	●	●	●	✓	✓	●	
Google	Pixel 3 XL	Android 9	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※7	①	✓	✓	✓	●	●	●	✓	✓	●	
Google	Pixel 2	Android 9	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3	①	✓	✓	✓	●	●	●	✓	✓	●	

- ※2 The number of incoming calls may not match the one shown on the device(mobile phone).
- ※3 Fast forward and fast reverse may not function during playback.
- ※5 The repeat folder, repeat one, and shuffle icons may not match the ones shown on the device(mobile phone).
- ※7 There may not be any sound output from the speaker during playback.
- ※8 After selecting song, song information may not appear.
- ✓ = Function is compatible with system operation
- ① = Function is compatible with system operation but may experience some limitations
- = This feature is not supported by this device at this time - please check back periodically for updates

Manufacturer	Device	Software Version	Basic Features				Advanced Features				Messaging			Entertainment		Indicators		USB Functions				Applications		
			Device OS	Device Pairing	Handsfree Calling	Incoming Call	Call Hangup	Call Waiting	Phonebook Import - Name/Phone #	Phonebook Import - Contact Pictures	Call History	SMS/Text - Receive Message	SMS/Text - Send Message	SMS/Text - Notification	Bluetooth Audio - Music	Bluetooth Audio - Displays Song Info	Battery Level	Signal Strength	USB Connection	Plays Music	USB - Displays Song Info	Music Controls	Charge Device	Android Auto
Huawei	P40 lite	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	⊖	⊖
Huawei	P40 lite E	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	⊖	⊖
Huawei	P30	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	P30 Pro	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	P30 lite	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	P20 Pro	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	P20 Lite	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	P10	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	P Smart (2019)	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	P smart Pro (2019)	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	P Smart Z	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Y7 (2019)	Android 8.1.0	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Y6 (2019)	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Y6 (2018)	Android 8	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※6	✓	✓	✓	✓	⊖	⊖	⊖	✓	① ※12	⊖
Huawei	Y6p	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	⊖	⊖
Huawei	Y6s	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Y5 (2019)	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Y5 Lite (2018)	Android 8.1.0	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※4	✓	✓	✓	✓	⊖	⊖	⊖	✓	⊖	⊖
Huawei	Y5p	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	⊖	⊖
Huawei	Mate 20 Pro	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Mate 20 Lite	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	View 20	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Honor 20	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※11	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Honor 20 Pro	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Honor 20 lite	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Honor 10 lite	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	⊖	⊖
Huawei	Honor 10i	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Honor 9X	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Honor 8A	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Honor 8S	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Honor 8X	Android 8.1.0	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Honor 7A	Android 8.0.0	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Huawei	Honor 7s	Android 8.1.0	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※6	✓	✓	✓	✓	⊖	⊖	⊖	✓	① ※12	⊖
Huawei	Nova 5T	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖

- ※2 The number of incoming calls may not match the one shown on the device(mobile phone).
- ※3 Fast forward and fast reverse may not function during playback.
- ※4 The repeat all icon may not be displayed.
- ※5 The repeat folder, repeat one, and shuffle icons may not match the ones shown on the device(mobile phone).
- ※6 The repeat mode and shuffle mode may not fully function.
- ※9 Android Auto may not be launched.
- ※11 After selecting folder, song information may not appear.
- ※12 Music app on Android Auto doesn't work normally.
- ✓ = Function is compatible with system operation
- ✗ = Function is NOT compatible with system operation
- ① = Function is compatible with system operation but may experience some limitations
- ⊖ = This feature is not supported by this device at this time - please check back periodically for updates

Manufacturer	Device	Software Version	Basic Features				Advanced Features				Messaging			Entertainment		Indicators		USB Functions				Applications			
			Device OS	Device Pairing	Handsfree Calling	Incoming Call	Call Hangup	Call Waiting	Phonebook Import - Name/Phone #	Phonebook Import - Contact Pictures	Call History	SMS/Text - Receive Message	SMS/Text - Send Message	SMS/Text - Notification	Bluetooth Audio - Music	Bluetooth Audio - Displays Song Info	Battery Level	Signal Strength	USB Connection	Plays Music	USB - Displays Song Info	Music Controls	Charge Device	Android Auto	Apple CarPlay
LG	Stylo 6	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※6	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖	
LG	Stylo 5	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	① ※8	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
LG	G8s ThinQ	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※4	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖	
LG	Q60	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※4	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖	
LG	K30	Android 8.1.0	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※4	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖	

- ※2 The number of incoming calls may not match the one shown on the device(mobile phone).
- ※3 Fast forward and fast reverse may not function during playback.
- ※4 The repeat all icon may not be displayed.
- ※5 The repeat folder, repeat one, and shuffle icons may not match the ones shown on the device(mobile phone).
- ※6 The repeat mode and shuffle mode may not fully function.
- ※8 After selecting song, song information may not appear.
- ✓ = Function is compatible with system operation
- ✗ = Function is NOT compatible with system operation
- ① = Function is compatible with system operation but may experience some limitations
- ⊖ = This feature is not supported by this device at this time - please check back periodically for updates

Manufacturer	Device	Software Version	Basic Features				Advanced Features				Messaging			Entertainment		Indicators		USB Functions				Applications			
			Device OS	Device Pairing	Handsfree Calling	Incoming Call	Call Hangup	Call Waiting	Phonebook Import - Name/Phone #	Phonebook Import - Contact Pictures	Call History	SMS/Text - Receive Message	SMS/Text - Send Message	SMS/Text - Notification	Bluetooth Audio - Music	Bluetooth Audio - Displays Song Info	Battery Level	Signal Strength	USB Connection	Plays Music	USB - Displays Song Info	Music Controls	Charge Device	Android Auto	Apple CarPlay
Motorola	Moto G Fast	Android 11	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	●	●	●	✓	✓	●		
Motorola	Moto G Play 2021	Android 11	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	●	●	●	✓	✓	●		
Motorola	Moto G Stylus	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	① ※8	✓	✓	✓	●	●	●	✓	✓	●	
Motorola	Moto G Power	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	① ※8	✓	✓	✓	●	●	●	✓	✓	●	
Motorola	Moto G9 play	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3	① ※8	✓	✓	✓	●	●	●	✓	✓	●	
Motorola	Moto G8 Plus	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	●	●	●	✓	✓	●	
Motorola	Moto G7	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	●	●	●	✓	✓	●	
Motorola	Moto G7 Plus	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※4	✓	✓	✓	✓	●	●	●	✓	✓	●	
Motorola	Moto G7 Play	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	●	●	●	✓	✓	●	
Motorola	Moto G7 Power	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	●	●	●	✓	✓	●	
Motorola	Moto G6 Plus	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	●	●	●	✓	✓	●	
Motorola	One	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	① ※8	✓	✓	✓	●	●	●	✓	✓	●	
Motorola	One Vision	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3	✓	✓	✓	✓	●	●	●	✓	✓	●	
Motorola	Moto E6	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	① ※8	✓	✓	✓	✓	●	●	●	✓	✓	●
Motorola	Moto E5 play	Android 8.1.0	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	●	●	●	✓	✓	●	

※2 The number of incoming calls may not match the one shown on the device(mobile phone).  
 ※3 Fast forward and fast reverse may not function during playback.  
 ※4 The repeat all icon may not be displayed.  
 ※5 The repeat folder, repeat one, and shuffle icons may not match the ones shown on the device(mobile phone).  
 ※8 After selecting song, song information may not appear.  
 ✓ = Function is compatible with system operation  
 ① = Function is compatible with system operation but may experience some limitations  
 ● = This feature is not supported by this device at this time - please check back periodically for updates

Manufacturer	Device	Software Version	Basic Features				Advanced Features				Messaging			Entertainment		Indicators		USB Functions				Applications		
			Device OS	Device Pairing	Handsfree Calling	Incoming Call	Call Hangup	Call Waiting	Phonebook Import - Name/Phone #	Phonebook Import - Contact Pictures	Call History	SMS/Text - Receive Message	SMS/Text - Send Message	SMS/Text - Notification	Bluetooth Audio - Music	Bluetooth Audio - Displays Song Info	Battery Level	Signal Strength	USB Connection	Plays Music	USB - Displays Song Info	Music Controls	Charge Device	Android Auto
Nokia	8.1	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	●	●	●	✓	✓	●
Nokia	4.2	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	① ※8	✓	✓	✓	●	●	●	✓	✓	●
Nokia	3	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	●	●	●	✓	✓	●
Nokia	2.3	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	●	●	●	✓	✓	●
Nokia	2.2	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3	✓	✓	✓	✓	●	●	●	✓	✓	●
Nokia	1 Plus	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3	✓	✓	✓	✓	●	●	●	✓	✓	●

※2 The number of incoming calls may not match the one shown on the device(mobile phone).  
 ※3 Fast forward and fast reverse may not function during playback.  
 ※5 The repeat folder, repeat one, and shuffle icons may not match the ones shown on the device(mobile phone).  
 ※8 After selecting song, song information may not appear.  
 ✓ = Function is compatible with system operation  
 ① = Function is compatible with system operation but may experience some limitations  
 ● = This feature is not supported by this device at this time - please check back periodically for updates

Manufacturer	Device	Software Version	Basic Features				Advanced Features				Messaging			Entertainment		Indicators		USB Functions				Applications		
			Device OS	Device Pairing	Handsfree Calling	Incoming Call	Call Hangup	Call Waiting	Phonebook Import - Name/Phone #	Phonebook Import - Contact Pictures	Call History	SMS/Text - Receive Message	SMS/Text - Send Message	SMS/Text - Notification	Bluetooth Audio - Music	Bluetooth Audio - Displays Song Info	Battery Level	Signal Strength	USB Connection	Plays Music	USB - Displays Song Info	Music Controls	Charge Device	Android Auto
OnePlus	8 Pro	Android 11	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	① ※8	✓	✓	✓	●	●	●	✓	✓	●
OnePlus	7TPro	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	① ※8	✓	✓	✓	●	●	●	✓	✓	●

※2 The number of incoming calls may not match the one shown on the device(mobile phone).  
 ※3 Fast forward and fast reverse may not function during playback.  
 ※5 The repeat folder, repeat one, and shuffle icons may not match the ones shown on the device(mobile phone).  
 ※8 After selecting song, song information may not appear.  
 ✓ = Function is compatible with system operation  
 ① = Function is compatible with system operation but may experience some limitations  
 ● = This feature is not supported by this device at this time - please check back periodically for updates

Manufacturer	Device	Software Version	Basic Features				Advanced Features				Messaging			Entertainment		Indicators		USB Functions				Applications		
			Device OS	Device Pairing	Handsfree Calling	Incoming Call	Call Hangup	Call Waiting	Phonebook Import - Name/Phone #	Phonebook Import - Contact Pictures	Call History	SMS/Text - Receive Message	SMS/Text - Send Message	SMS/Text - Notification	Bluetooth Audio - Music	Bluetooth Audio - Displays Song Info	Battery Level	Signal Strength	USB Connection	Plays Music	USB - Displays Song Info	Music Controls	Charge Device	Android Auto
OPPO	A53	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	① ※8	✓	✓	✓	●	●	●	✓	✓	●
OPPO	A15	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	① ※8	✓	✓	✓	●	●	●	✓	✓	●
OPPO	A12	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※6	✓	✓	✓	✓	●	●	●	✓	✓	●
OPPO	A9 (2020)	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※6	✓	✓	✓	✓	●	●	●	✓	✓	●
OPPO	A5 (2020)	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※6	✓	✓	✓	✓	●	●	●	✓	✓	●
OPPO	AX7	Android 8.1.0	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3	✓	✓	✓	✓	●	●	●	✓	✓	●

※2 The number of incoming calls may not match the one shown on the device(mobile phone).  
 ※3 Fast forward and fast reverse may not function during playback.  
 ※5 The repeat folder, repeat one, and shuffle icons may not match the ones shown on the device(mobile phone).  
 ※6 The repeat mode and shuffle mode may not fully function.  
 ※8 After selecting song, song information may not appear.  
 ✓ = Function is compatible with system operation  
 ① = Function is compatible with system operation but may experience some limitations  
 ● = This feature is not supported by this device at this time - please check back periodically for updates

Manufacturer	Device	Software Version	Basic Features				Advanced Features				Messaging			Entertainment		Indicators		USB Functions				Applications		
			Device OS	Device Pairing	Handsfree Calling	Incoming Call	Call Hangup	Call Waiting	Phonebook Import - Name/Phone #	Phonebook Import - Contact Pictures	Call History	SMS/Text - Receive Message	SMS/Text - Send Message	SMS/Text - Notification	Bluetooth Audio - Music	Bluetooth Audio - Displays Song Info	Battery Level	Signal Strength	USB Connection	Plays Music	USB - Displays Song Info	Music Controls	Charge Device	Android Auto
Realme	8 5G	Android 11	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	●	●	●	✓	✓	●
Realme	C15	Android 11	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	✓	✓	✓	✓	●	●	●	✓	✓	●
Realme	C11	Android 10	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※5	① ※8	✓	✓	✓	●	●	●	✓	✓	●
Realme	C2	Android 9	✓	✓	✓	✓	✓	✓	✓	① ※2	✓	✓	✓	① ※3※6	✓	✓	✓	✓	●	●	●	✓	✓	●

※2 The number of incoming calls may not match the one shown on the device(mobile phone).  
 ※3 Fast forward and fast reverse may not function during playback.  
 ※5 The repeat folder, repeat one, and shuffle icons may not match the ones shown on the device(mobile phone).  
 ※6 The repeat mode and shuffle mode may not fully function.  
 ※8 After selecting song, song information may not appear.  
 ✓ = Function is compatible with system operation  
 ① = Function is compatible with system operation but may experience some limitations  
 ● = This feature is not supported by this device at this time - please check back periodically for updates



Samsung	Galaxy S7	Android 8.0.0	✓	ⓘ ※1	✓	✓	✓	✓	✓	ⓘ ※2	✓	✓	✓	ⓘ ※3※4	✓	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Samsung	Galaxy X Cover Pro	Android 11	✓	✓	✓	✓	✓	✓	✓	ⓘ ※2	✓	✓	✓	ⓘ ※3※5	✓	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Samsung	Galaxy XCover4	Android 10	✓	✓	✓	✓	✓	✓	✓	ⓘ ※2	✓	✓	✓	ⓘ ※3※5	✓	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Samsung	Galaxy XCover4	Android 9	✓	✓	✓	✓	✓	✓	✓	ⓘ ※2	✓	✓	✓	ⓘ ※3※4	✓	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Samsung	Galaxy XCover4s	Android 10	✓	✓	✓	✓	✓	✓	✓	ⓘ ※2	✓	✓	✓	ⓘ ※3※5	ⓘ ※8	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
Samsung	Galaxy XCover4s	Android 9	✓	✓	✓	✓	✓	✓	✓	ⓘ ※2	✓	✓	✓	ⓘ ※3※4	✓	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖

- ※1 The audio output during a call cannot be switched between Bluetooth Hands-Free and the device(mobile phone)
- ※2 The number of incoming calls may not match the one shown on the device(mobile phone).
- ※3 Fast forward and fast reverse may not function during playback.
- ※4 The repeat all icon may not be displayed.
- ※5 The repeat folder, repeat one, and shuffle icons may not match the ones shown on the device(mobile phone).
- ※8 After selecting song, song information may not appear.
- ※15 Album cover is not same as the device.(mobile phone)
- ✓ = Function is compatible with system operation
- ⓘ = Function is compatible with system operation but may experience some limitations
- ⊖ = This feature is not supported by this device at this time - please check back periodically for updates
- ⊗ = This function has not been tested on this device

Manufacturer	Device	Software Version	Basic Features				Advanced Features				Messaging			Entertainment		Indicators		USB Functions					Applications	
			Device OS	Device Pairing	Handsfree Calling	Incoming Call	Call Hangup	Call Waiting	Phonebook Import - Name/Phone #	Phonebook Import - Contact Pictures	Call History	SMS/Text - Receive Message	SMS/Text - Send Message	SMS/Text - Notification	Bluetooth Audio - Music	Bluetooth Audio - Displays Song Info	Battery Level	Signal Strength	USB Connection	Plays Music	USB - Displays Song Info	Music Controls	Charge Device	Android Auto
SONY	Xperia 1	Android 10	✓	✓	✓	✓	✓	✓	ⓘ ※2	✓	✓	✓	ⓘ ※3	✓	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖
SONY	Xperia XA2	Android 9	✓	✓	✓	✓	✓	✓	ⓘ ※2	✓	✓	✓	ⓘ ※3※5	✓	✓	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖

- ※2 The number of incoming calls may not match the one shown on the device(mobile phone).
- ※3 Fast forward and fast reverse may not function during playback.
- ※5 The repeat folder, repeat one, and shuffle icons may not match the ones shown on the device(mobile phone).
- ✓ = Function is compatible with system operation
- ⓘ = Function is compatible with system operation but may experience some limitations
- ⊖ = This feature is not supported by this device at this time - please check back periodically for updates

Manufacturer	Device	Software Version	Basic Features				Advanced Features				Messaging			Entertainment		Indicators		USB Functions					Applications	
			Device OS	Device Pairing	Handsfree Calling	Incoming Call	Call Hangup	Call Waiting	Phonebook Import - Name/Phone #	Phonebook Import - Contact Pictures	Call History	SMS/Text - Receive Message	SMS/Text - Send Message	SMS/Text - Notification	Bluetooth Audio - Music	Bluetooth Audio - Displays Song Info	Battery Level	Signal Strength	USB Connection	Plays Music	USB - Displays Song Info	Music Controls	Charge Device	Android Auto
TCL	20 SE	Android 11	✓	✓	✓	✓	✓	✓	ⓘ ※2	✓	✓	✓	ⓘ ※3※5	ⓘ ※8	✓	✓	✓	⊖	⊖	⊖	✓	✓	⊖	

- ※2 The number of incoming calls may not match the one shown on the device(mobile phone).
- ※3 Fast forward and fast reverse may not function during playback.
- ※5 The repeat folder, repeat one, and shuffle icons may not match the ones shown on the device(mobile phone).
- ※8 After selecting song, song information may not appear.
- ✓ = Function is compatible with system operation
- ⓘ = Function is compatible with system operation but may experience some limitations
- ⊖ = This feature is not supported by this device at this time - please check back periodically for updates

Manufacturer	Device	Software Version	Basic Features				Advanced Features				Messaging			Entertainment		Indicators		USB Functions				Applications	
			Device OS	Device Pairing	Handsfree Calling	Incoming Call	Call Hangup	Call Waiting	Phonebook Import - Name/Phone #	Phonebook Import - Contact Pictures	Call History	SMS/Text - Receive Message	SMS/Text - Send Message	SMS/Text - Notification	Bluetooth Audio - Music	Bluetooth Audio - Displays Song Info	Battery Level	Signal Strength	USB Connection	Plays Music	USB - Displays Song Info	Music Controls	Charge Device
Xiaomi	Redmi 10A	Android 11	✓	✓	✓	✓	✓	①	①	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi 10C	Android 13	✓	✓	✓	✓	✓	①	①	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi 9	Android 10	✓	✓	✓	✓	✓	✓	✗	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	✗
Xiaomi	Redmi 9A	Android 11	✓	✓	✓	✓	✓	①	①	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi 9A	Android 10	✓	✓	✓	✓	✓	✓	✗	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi 9C	Android 10	✓	✓	✓	✓	✓	①	①	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi 9C	Android 10	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi 8	Android 9	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi 8A	Android 9	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi 7	Android 9	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi 7A	Android 10	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi 7A	Android 9	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi 6A	Android 9	✓	✓	✓	✓	✓	✓	✗	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi GO	Android 8.1.0	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi Note 11 Pro	Android 13	✓	✓	✓	✓	✓	①	①	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi Note 10	Android 11	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi Note 10 Pro	Android 13	✓	✓	✓	✓	✓	①	①	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi Note 9	Android 10	✓	✓	✓	✓	✓	✓	✗	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi Note 9 Pro	Android 10	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi Note 8	Android 9	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi Note 8 Pro	Android 10	✓	✓	✓	✓	✓	✓	✗	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi Note 8T	Android 10	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi Note8 Pro	Android 9	✓	✓	✓	✓	✓	✓	✗	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Redmi Note7	Android 9	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Mi 11 Lite 5G	Android 11	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Mi 10T Lite 5G	Android 10	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Mi 10 Lite	Android 11	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	✗
Xiaomi	Mi 9	Android 10	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Mi 9 SE	Android 10	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Mi 9T	Android 10	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Mi 9T	Android 9	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Mi 9T Pro	Android 10	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Mi9 Lite	Android 10	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Mi A3	Android 9	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Mi A2 Lite	Android 9	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Mi A1	Android 9	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Mi Note 10	Android 10	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①
Xiaomi	Mi Note 10 Lite	Android 11	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	✗
Xiaomi	Poco M3	Android 10	✓	✓	✓	✓	✓	✓	✓	①	✓	✓	✓	①	①	①	①	①	①	①	①	①	①

- ※2 The number of incoming calls may not match the one shown on the device(mobile phone).
- ※3 Fast forward and fast reverse may not function during playback.
- ※4 The repeat all icon may not be displayed.
- ※5 The repeat folder, repeat one, and shuffle icons may not match the ones shown on the device(mobile phone).
- ※8 After selecting song, song information may not appear.
- ※9 Android Auto may not be launched.
- ※10 Photo in contact has not been forwarded.
- ※11 After selecting folder, song information may not appear.
- ※14 It is not able to pause music by pause button.
- ※15 Album cover is not same as the device.(mobile phone)
- ✓ = Function is compatible with system operation
- ✗ = Function is NOT compatible with system operation
- ① = Function is compatible with system operation but may experience some limitations
- ② = This feature is not supported by this device at this time - please check back periodically for updates
- ③ = This function has not been tested on this device